

Fitting instructions

ATTENTION!
Ensure Splashblade®
bracket has magnetic
side facing the shower.



Splashblade® is specially designed to stop all those annoying and costly leaks which happen when your over-bath shower/shower cubical sprays out water between the curtain and the wall.

For no more leaks simply install the magnetic Splashblade® wall bracket as directed, clip the special folding magnets onto the edge of your shower curtain, close the curtain – *and that's it, job done!*

Tools/equipment required:

- Spirit level
- Tube silicon sealant
- Stanley/craft knife
- Drill
- 50mm long screws x 2 with red plugs

Installation:

- (1) Mark both positions for Splashblade® bracket on the wall; we recommend doing this with the key hole parallel to the wall (see image opposite (A))
- (2) Drill the holes as required and insert both screws.
- (3) Ensure Splashblade® bracket has magnetic side facing the shower.
- (4) Slot the Splashblade® onto the screws. If the Splashblade® is slightly loose take off and adjust the screws accordingly.
- (5) Finish both edges between bracket and wall/bath with a bead of silicon sealant. For best results trim Silicon tube nozzle as small as possible to achieve neatest bead.
- (6) Straight away remove excess sealant with clean fingertip; then clean and wet fingertip to finally smooth sealant.
- (7) Clean hands and dispose of excess sealant responsibly – that's the installation done!

...and finally to use:

- (8) Clip the 6 folding magnets (supplied in package) to the edge of the shower curtain, spacing them evenly (see image opposite (B))
- (9) Pull shower curtain towards wall until magnets grab the Splashblade wall bracket to close the gap.



27 Wingerworth Avenue • Sheffield • United Kingdom • S8 7ED

tel: +44(0)114 2359048 • email: info@splashblade.com • www.splashblade.com