

**ATTENTION!**  
Ensure Splashblade®  
bracket has magnetic  
side facing the shower.



# Fitting instructions

Splashblade® is specially designed to stop all those annoying and costly leaks which happen when your over-bath shower sprays out water between the curtain and the wall.

For no more leaks simply install the magnetic Splashblade® wall bracket as directed, clip the special folding magnets onto the edge of your shower curtain, close the curtain – *and that's it, job done!*

## Tools/equipment required:

- Spirit level
- Tube silicon sealant
- Stanley/craft knife
- Alcohol-based cleanser

## Preparation for installation:

1. Check that the wall is flat with no bumps, clean and dry (see Fig. 1), and that there are no obstructions to fitting of the Splashblade® wall bracket. Ensure this will fit flush right into corner of bath and wall – remove existing bath sealant/trim as required. We recommend using the alcohol-based wipe (supplied in package) to remove all grease, soap etc. from the tiled area where Splashblade® will be fitted to. Allow area to dry for a few minutes.
2. Mark position for Splashblade® bracket on the wall; we recommend doing this with masking tape on tiles (see Fig. 2) or pencil line using spirit level. Ensure line is vertical and outer edge of bracket is 2.5cm (1") in from edge of bath.

## Installation:

3. Ensure Splashblade® bracket has magnetic side facing the shower. Peel off release paper from self-adhesive backing on Splashblade® wall bracket. Offer up to wall, resting the bottom on bath edge, align with vertical wall marking and press onto wall using firm even pressure (see Fig. 3). Please take care with installation since adhesive is strong and not readily repositionable in the event of a mistake.
4. Finish both edges between bracket and wall/bath with a bead of silicon sealant (see Fig. 4). For best results trim silicon tube nozzle as small as possible to achieve neatest bead.
5. Straight away remove excess sealant with clean fingertip; then clean and wet fingertip to finally smooth sealant.
6. Clean hands and dispose of excess sealant responsibly – that's the installation done!

## ...and finally to use:

7. Clip the 4 folding magnets (supplied in package) to the edge of the shower curtain, spacing them evenly (see Fig 5).
8. Pull shower curtain towards wall (see Fig. 6) until magnets grab the Splashblade® wall bracket to close the gap.

# it's as easy as that!

